

K59M



Split Ergonomic RGB Mechanical Keyboard



HOTKEY QUICK REFERENCE





CHANGE BACKLIGHTING EFFECTS 

LOCKOUT Windows® KEY (GAME MODE) 

TURN OFF/ON KEYBOARD BACKLIGHTS  + 

TURN OFF/ON SMART WHEEL BACKLIGHT  + 

CHANGE SMART WHEEL MODE.....  + 
(click)

MODE	COLOR		 (click)	 + 
Volume	White	Up / Down	Mute	-
Application	Red	Switch	Select	-
Scroll	Blue	Up / Down	-	-
Brightness	Green	Adjust Brightness	Change Color	Backlight Speed

快速操作指南

切換背光特效 

鎖定 Windows® 鍵 (遊戲模式) 

開啟或關閉鍵盤背光  + 

開啟或關閉智慧轉輪背光  + 

切換智慧轉輪模式.....  + 
(click)

模式	滾輪顏色		 (click)	 + 
音量	白色	大聲 / 小聲	靜音	-
工作頁面	紅色	切換	選定	-
滾輪	藍色	上捲 / 下捲	-	-
背光	綠色	調整亮度	變更顏色	變更速度



Download the app to upgrade to the latest firmware,
customize backlighting, program macros, and more...

下載鍵盤專屬設定程式，以便您升級韌體、自訂背光、
錄製巨集與探索更多功能


www.i-rocks.com

Model No. : IRK59M
Quick Installation Guide

KEYBOARD LAYOUT



K



L



M

N




- A** Media Hotkeys
- B** Smart Control Wheel
- C** Windows® Lockout Key
- D** Backlighting Key
- E** Macro Keys

- F** Fn Key
- G** Keyboard Interface (R)
- H** Keyboard Interface (L)
- I** USB Pass-Through Port
- J** Keyboard Port

- K** Linking Cable
- L** Keyboard Cable
- M** Keycap Puller
- N** Extra Esc & Macro Keycaps


SETTING UP YOUR KEYBOARD

1. Connect the linking cable (A,B) to each of the keyboard halves.
(Note : icon logo faces up.)
2. Connect the keyboard cable (C) to a free USB-A port on your Windows® PC or Apple Mac®.






SMART CONTROL WHEEL

Pressing the Fn key (A) + Smart Control Wheel (B) will cycle through the available modes with the color changing to indicate the current mode. After selecting a mode, rotate the wheel left, right, or click to adjust mode settings.




Smart Control Wheel backlighting can be turned on/off by pressing the Fn key (A) + "Q" key.

MODE	COLOR		 (click)	
Volume	White	Up / Down	Mute	-
Application	Red	Switch	Select	-
Scroll	Blue	Up / Down	-	-
Brightness	Green	Adjust Brightness	Change Color	Backlight Speed

BACKLIGHTING EFFECTS

Keyboard backlighting effects can be changed by pressing the backlighting key (A).

All backlighting can be turned on/off by pressing the Fn key (B) + backlighting key (A).



Smart Control Wheel backlighting can be turned on/off by pressing the Fn key (B) + "Q" key.


MACRO KEYS

Macros can be recorded at any time (without software) via on board commands. The keyboard supports a maximum of 16 key combinations per macro.

The macro functions : Select **All / Copy / Paste / Cut** are preprogrammed into the 4 macro M-keys (B).

To assign a new macro function, follow these steps :


1. Press the Fn key (C) + any single macro M-key (B) to start recording.
2. The "M" LED (A) will flash and the new key combination is ready to be recorded.
Enter a new macro key combination.
3. Press the Fn key (C) + the same macro M-key (B) again to save the recording.
The "M" LED (A) will flash 3 times indicating the macro was successfully saved.



To clear all custom macros and restore factory settings, press the Fn key (C) + "Esc" key and hold for 3 seconds.


MEDIA HOTKEYS

- Fn key (B) + F1 key (A) **Media Player**
- Fn key (B) + F2 key (A) **Play/Pause**
- Fn key (B) + F3 key (A) **Stop**
- Fn key (B) + F4 key (A) **Previous**
- Fn key (B) + F5 key (A) **Next**




WINDOWS® LOCKOUT KEY (GAME MODE)

- Windows lockout key (A) disables the Windows® key.




FACTORY RESET

To return the keyboard to its factory settings, press the Fn key (A) + “Esc” key and hold for 3 seconds.



Note : All custom programmed macros and backlight colors will be erased when the keyboard is returned to factory settings.

鍵盤功能配置




- A** 多媒體熱鍵
- B** 智慧滾輪
- C** 鎖Windows® 鍵
- D** 背光特效
- E** 快捷鍵

- F** Fn 鍵
- G** 右鍵盤連接埠(R)
- H** 左鍵盤連接埠 (L)
- I** USB 2.0 輸出埠
- J** USB 主線連接埠

- K** 鍵盤傳輸連接線 (23 CM)
- L** 鍵盤主線連接線 (180 CM)
- M** 拔鍵器
- N** 延伸替換鍵


鍵盤安裝

1. 鍵盤傳輸連接線連結於 (A,B) 點。(兩邊圖示ICON 要朝上)
2. 連接主連接線於鍵盤 (C), 另一邊連接電腦端的 USB-A埠



智慧轉輪

- 按壓Fn鍵 (A) + 滾輪 (B) 進行滾輪模式切換，共有四種模式及對應的背光。
- 按壓Fn鍵 (A) + Q鍵，可關閉/開啟滾輪背光。



模式

轉輪顏色



音量

白色

大聲 / 小聲

靜音

-

工作頁面

紅色

切換

選定

-

滾輪

藍色

上捲 / 下捲

-

-

背光

綠色


調整亮度

變更顏色

變更速度

背光特效


- 按壓 背光特效切換按鍵(A) 可進行背光特效切換,共有20種背光特效可以提供選擇。
- 按壓Fn (B) + 背光特效切換按鍵(A) 可將背光進行開跟關。



- 按壓Fn鍵 (B) + Q鍵, 可關閉/開啟滾輪背光

巨集鍵


1. 軟體巨集錄製請安裝對應軟體進行操作。
2. 直接鍵盤硬體錄製，支援4 組(M1 ~M4)(B) 自定巨集功能，並且儲存於鍵盤內存記憶體中，操作方式如下：
 - a. 選擇要錄製的M1~M4其中一鍵按鍵 (例如 M1)
 - b. 按Fn鍵 (C) +M1 (B)開始錄製 (M指示燈會慢閃)
 - c. 鍵入所欲錄製的字元，最大支援16字元 (超出部分不會被錄製)
錄製時間要在3分鐘內完成，超過時間將自動結束不保存
 - d. 再次按壓Fn+M1 保存 (MR指示燈快閃3次熄滅，完成儲存)
 - e. 其他M1~M4 錄製方式同上
 - f. 按壓M1~M4 叫出所錄製的巨集
3. M1~M4 內定的功能分別為Select all / Copy / Paste/ Cut



注意: Fn+ESC 3秒鐘清除所有巨集設定，恢復原廠設定


多媒體熱鍵功能

- Fn key (B) + F1 key (A) 多媒體播放
- Fn key (B) + F2 key (A) 播放
- Fn key (B) + F3 key (A) 停止
- Fn key (B) + F4 key (A) 上一首
- Fn key (B) + F5 key (A) 下一首




鎖WINDOWS®按鍵功能

- 可開啟跟關閉WINDOWS按鍵功能



恢復原廠設定

- 按壓 FN鍵 (A) + ESC 鍵 約3秒鐘可恢復原廠設定



注意：恢復原廠設定後所有的按鍵巨集及背光設定值將被清除，恢復出廠值。



線上產品註冊登入

- 1.至會員專區
- 2.加入或登入會員
- 3.完成產品註冊

www.i-rocks.com.tw

i-Rocks Technology Co., Ltd.

Headquarter Office

7F., No. 786, Zhongzheng Rd., Zhonghe Dist.,
New Taipei City 23586, Taiwan

Tel : +886-2-2225-5080

Fax : +886-2-2228-1712

www.i-rocks.com

i-Rocks Korea

www.i-rocks.co.kr

i-Rocks Malaysia

57-A, Jalan SS21/1A, Damansara Utama, 47400,
Petaling Jaya, Selangor, Malaysia

Tel : +603-77339233

www.i-rocks.com

IRK59M

