

K74M Firmware Upgrade Guide

It's recommended to check for firmware upgrade for your keyboard before using it for the first time.

Changelog:

- Firmware version: K10.08
- Fixing and optimizing the backlight memory function when turned off.
Fixing the customizing the 4 and 5th backlight setting group.

Upgrade Steps:

1. Connect your keyboard and your PC via USB cable
2. Run the firmware upgrade program. It will take approximately 2 to 4 seconds to detect the keyboard device.
3. Once the device is detected, the update program will automatically initiate the update process. It will close automatically when the update is completed.
4. After the update is finished, please disconnect and reconnect the keyboard to allow the computer to recognize the keyboard device again.
5. Done.

DO NOT UNPLUG THE USB CABLE, TURN OFF OR RESTART YOUR PC WHILE UPGRADING.

